


* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009


21 INT 1.2/00



* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

21 INT 1.3/00




Eldas 964 752 209 - 964 752 289 **Art.344642 - 344643**



Etagen-Taster
Poussoir d'étage
 Chiamata al piano

Entfernen Sie J1 / Retirez le J1 / Rimuovi J1

Art.346020
 Eldas 964 930 490




Eldas 964 752 209 - 964 752 289 **Art.344642 - 344643**



Etagen-Taster
Poussoir d'étage
 Chiamata al piano

Entfernen Sie J1 / Retirez le J1 / Rimuovi J1

Art.346020
 Eldas 964 930 490




Eldas 964 752 209 - 964 752 289 **Art.344642 - 344643**



Etagen-Taster
Poussoir d'étage
 Chiamata al piano

Entfernen Sie J1 / Retirez le J1 / Rimuovi J1

Art.346020
 Eldas 964 930 490




Eldas 964 752 209 - 964 752 289 **Art.344642 - 344643**



Etagen-Taster
Poussoir d'étage
 Chiamata al piano

Entfernen Sie J1 / Retirez le J1 / Rimuovi J1

Art.346020
 Eldas 964 930 490




Eldas 964 752 209 - 964 752 289 **Art.344642 - 344643**



Etagen-Taster
Poussoir d'étage
 Chiamata al piano

Entfernen Sie J1 / Retirez le J1 / Rimuovi J1

Art.346020
 Eldas 964 930 490



Eldas 964 752 209 - 964 752 289 **Art.344642 - 344643**



Etagen-Taster
Poussoir d'étage
 Chiamata al piano

Entfernen Sie J1 / Retirez le J1 / Rimuovi J1

Art.346020
 Eldas 964 930 490

21 INT 1.1/00

*** 1-4 (Strang / Colonne montante / Montante)**
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: **Verdrillte kabel verwenden / Utiliser des câbles torsadés**
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

