


* 1-4 (Strang / Colonne montante / Montante)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

22 INT 1.2/00

*1




*1

21 TAB 1.1/00

* 1-4 (Strang / Colonne montante / Montante)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009


22 INT 1.3/00



Eldas 964 752 009 - 964 752 089 **Art.344612 - 344613**

J1 J2 N P M
 JUMP JUMP 6


Etagen-Taster
Poussoir d'étage
 Chiamata al piano



Eldas 964 752 009 - 964 752 089 **Art.344612 - 344613**

J1 J2 N P M
 JUMP JUMP 5


Etagen-Taster
Poussoir d'étage
 Chiamata al piano



Eldas 964 752 009 - 964 752 089 **Art.344612 - 344613**

J1 J2 N P M
 JUMP JUMP 4


Etagen-Taster
Poussoir d'étage
 Chiamata al piano



Eldas 964 752 009 - 964 752 089 **Art.344612 - 344613**

J1 J2 N P M
 JUMP JUMP 3


Etagen-Taster
Poussoir d'étage
 Chiamata al piano



Eldas 964 752 009 - 964 752 089 **Art.344612 - 344613**

J1 J2 N P M
 JUMP JUMP 2

Etagen-Taster
Poussoir d'étage
 Chiamata al piano



Eldas 964 752 009 - 964 752 089 **Art.344612 - 344613**

J1 J2 N P M
 JUMP JUMP 1














Etagen-Taster
Poussoir d'étage
 Chiamata al piano

22 INT 1.1/00

* 1-4 (Strang / Colonne montante / Montante)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

22 INT 1.4/00




22 INT 1.2/00

* 1-4 (Strang / Colonne montante / Montante)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

22 INT 1.5/00

*1



Eldas 964 752 009 - 964 752 089

Art.344612 - 344613

J1 J2 N P M
 JUMP JUMP 16

Eldas 964 752 009 - 964 752 089

Art.344612 - 344613

J1 J2 N P M
 JUMP JUMP 15

Eldas 964 752 009 - 964 752 089

Art.344612 - 344613

J1 J2 N P M
 JUMP JUMP 14

Eldas 964 752 009 - 964 752 089

Art.344612 - 344613

J1 J2 N P M
 JUMP JUMP 13



22 INT 1.3/00

*1

* 1-4 (Strang / Colonne montante / Montante)

Info: **Verdrillte kabel verwenden / Utiliser des câbles torsadés**
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

23 INT 1.6/00









22 INT 1.4/00

* 1-4 (Strang / Colonne montante / Montante)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

22 INT 1.7/00



22 INT 1.5/00

* 1-4 (Strang / Colonne montante / Montante)

Info: Verdrillte kabel verwenden / Utiliser des câbles torsadés
Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

