






* 1-4 (Strang / Colonne montante / Montante)

X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X^i:à|c^Áaa^|c^i, ^} à} ÁWã^i/Á^Áèa^Ái:æ...
Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

21 INT 1.6/00



21 INT 1.4/00

* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X\à\à\c\A\æ\|ç\^, ^} à\} Á\W\ã\^|á\^•&è\^Á\i\æ...
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

