














\* 1-4 (Strang / Colonne montante / Montante)

**X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)**

Info: X^i:à|c^Áæ^|ç^i, ^} à} ÁWç^i/Á^Áè^Ái:æ...  
Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

21 INT 1.6/00



21 INT 1.4/00





\* 1-4 (Strang / Colonne montante / Montante)  
**X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)**

Info: X...  
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

