



* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X^!|á|ä|é|à|è|ä|é|, ^|á|ä|é|à|è|ä|é|...
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

21 INT 1.2/00
 *1

41 INT 1.2/06
 *2



21 TAB 1.1/00

41 TAB 1.1/06

* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X...
Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

