

* 1-4 (Strang / Colonne montante / Montante)



X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X^i^a^i^c^A^æ^A^s^i^ ^) ^a^ ^A^W^a^A^A^•A^è^a^•A^i^•æ^..:

Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

21 INT 1.2/00

41 INT 1.2/06



21 TAB 1.1/00

41 TAB 1.1/06

