



* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X^!à!à!c^Áæ^!Á^!, ^) à^! Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!Á^!
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009









* 1-4 (Strang / Colonne montante / Montante)

X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Utilizzare cavi twistati Art.336904 - Eldas 101 282 009



*1
21 INT 1.2/00

*2
41 INT 1.2/06