









\* 1-4 (Strang / Colonne montante / Montante)  
**X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)**

Info: X^!|à|c|Ä|æ|Ä|,|,| ^| à| | Ä|W|ä|Ä|•|Ä|è|Ä|•|Ä|!|•|æ|..|  
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009



21 INT 1.3/00

41 INT 1.3/06