



* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X^!à!à!c^Áæ^!Á^!, ^) à^! Á^Á^á^!Á^•Áè!Á^•Á! :æ!..
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

21 INT 1.3/00
 *1

41 INT 1.3/06
 *2



21 INT 1.1/00
 *1

41 INT 1.1/06
 *2

* 1-4 (Strang / Colonne montante / Montante)
X (Entfernen Sie J1 / Retirez le J1 / Rimuovi J1)

Info: X^!à!q|c Áæ^|Á^!, ^} á^} ÁWá^!Á^•Áéà^•Á^!•á...
 Utilizzare cavi twistati Art.336904 - Eldas 101 282 009

